


EuroTote as a Bunting/Stroller Bag

The EuroTote may be used as a bunting bag in strollers, car seats, bike trailers, ski sleds, etc. with both 3 and 5 point harnesses.

5-Point Harness



1. Place EuroTote in Seat

- Place the EuroTote in the seat and open EuroTote to reach inside.
- Pull stroller harness straps through the slot openings on the back of the EuroTote;
 - for 5-point harness use vertical slots.
 - for 3-point harness use vertical top slot.
- Pull the bottom buckle through whichever of the two vertical slots located between your child's legs that is compatible to your child's size.

2. Fasten Harness over Child


Place child in seat and fasten safety harness over child.

3. Zip Up and Go

Ensure that all straps and buckles are stored away. Zip warming top to keep child warm.

Unzip or close the EuroTote to regulate your child's temperature as weather and temperature change.

3-Point Harness



Practical and Helpful Hints:

- For maximum warmth, adjust the EuroTote to your child's length by attaching the bottom hook to the front *or* back of the bag.
- Also for maximum warmth; fold the side flaps over your child and attach the swaddle straps.
- Close up hood to protect against wind and cold.
- When not in use, fold hood over the back of the seat and tighten the hood strap to ensure the back stays up.
- Insert all straps into the corresponding pockets when not in use.
- Simplify getting ready by leaving the EuroTote in the stroller or car seat. As the top zips off, the EuroTote may also serve as a soft seat cover on warmer days.
- Two way zippers allow you to regulate your child's temperature by opening up or closing up as needed.
- Unbutton the front "storm flap" to block sun, or wind and rain.
- Zippers open on the bottom allowing growing feet (or dirty shoes) to stick out.



To-way zippers



Adjust length