

lillebaby™

EuroTote™ Owners Manual



IMPORTANT!

Carefully read this manual and all safety warnings before use.

Please do not hesitate to contact us if you have any questions. Please contact Scandinavian Child at: 1.866.782.6222 or go to www.SCICChild.com
Keep this manual for future reference.

www.lillebabyusa.com

WARNING

Failure to follow these warnings could result in serious injury or death.

- **NEVER LEAVE CHILD UNATTENDED.**
- **DO NOT** use this product in place of motor vehicle car seat OR if product interferes with motor vehicle restraints.
- **ALWAYS** carry child horizontally with face up.
- **DO NOT** use if carrier is damaged or broken.

FALL HAZARD

NEVER place or hang carrier on a table, countertop or other elevated surface or hook. **DO NOT** use carrier unless child is properly secured and **ALL** straps are securely fastened. **DO NOT** use carrier if child can crawl, roll or fall out. **ALWAYS** support the carrier with your hands and arms when carrying.

STRANGULATION HAZARD

Children can strangle in loose or long straps. **NEVER** leave child in product when straps are loose or undone or if child can find hidden straps. **ALWAYS** insert loose straps into product away from child's reach.

SUFFOCATION HAZARD

Carrier can roll over on soft or sloped surfaces and suffocate child. **NEVER** place carrier on beds, sofas or other soft or sloped surfaces.

ONLY use carrier for children between 8 lbs (3.5 kg) and 21 inches (53 cm) long and 25 lbs (11 kg).



TWO YEAR MANUFACTURER'S LIMITED WARRANTY

To the original consumer purchaser of this product lillébaby warrants this product to be free from defects in material and workmanship existing at the time of manufacture under normal household use in accordance with the instructions for a period of two (2) years from the date of purchase.

If lillébaby determines that the product is defective, lillébaby at its sole discretion shall repair, refund or replace your product at no cost to you. This warranty shall not apply to damages resulting from misuse, failure to follow the instructions, abuse, alteration, involvement in an accident and normal wear and tear. This is a limited warranty. Liability for consequential damages is expressly excluded. Proof of purchase is required.

To make a claim under this warranty please contact Scandinavian Child at 1-866-782-6222 to speak with a customer service representative or send a consumer inquiry online at www.lillebabyusa.com/customer_service.cfm. Please have the product number ready. The product number is located on the care label sewn into the EuroTote. A return authorization number may be required. You also can write us at lillébaby Product Support, c/o Scandinavian Child LLC, P.O. Box 31243, Raleigh, NC 27622 or e-mail Lillebaby@SClchild.com.

No other warranty is given for this product. All other warranties, including implied warranties of merchantability and/or fitness for a particular purpose are hereby expressly disclaimed.

Some states do not allow an exclusion or limitation of special, incidental or consequential damages, therefore, that limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

lillébaby products, the lillébaby brand and the EuroTote are protected by patent, patents pending and trademark rights. Exclusive distributor in the USA and Canada for lillébaby is Scandinavian Child LLC, P.O. Box 31243, Raleigh, NC 27622.

© lillébaby llc

About the lillébaby™ EuroTote™

Congratulations on your new EuroTote - traveling with baby just got easier!

The EuroTote starts out as a practical Moses Carrier and morphs into a Bunting and Stroller Bag, as well as a Play Blanket and Travel Bedding. It continues to add value as it grows with your child over three years and provides year round use with interchangeable tops.

Carrying your child in a Moses Carrier is a time-tested technique that goes back centuries. With the winter warming top, the EuroTote swaddles, calms, warms and carries your child all in one. With the mesh top it is literally the **coolest carrier** available.

The EuroTote's **calming effect** on babies lays in making baby's transition into the world a softer experience; the technique simulates mommy's belly and gives baby a home-away-from-home. It has a familiar touch and feel and calming reassurance of seeing mommy's face; your child is not forced to take in the exteriors, but is instead protected from over stimulation.

More importantly: horizontally is the most protective way to transport a baby. Research show that leaving baby in car seats or in an upright position may have multiple negative effects, including causing stress on the still developing spine, delayed motor development and reducing your child's intake of oxygen after as little as 20 minutes in the seat (a.k.a. oxygen desaturation).

The EuroTote Moses Carrier **fits directly into car seats** (Crash tested- FMVSS 213). This allows you to simply unbuckle car seat harness straps and carry your baby with you. Your baby gets a break from sitting; you get a break leaving the 9 lb car seat behind.


When your child is too heavy to be carried, continue enjoying the many functions and features of the EuroTote until your child is three years old.

Carefully read this manual to make the most out of your EuroTote. Understanding its intelligent design and many smart features will allow you to use the EuroTote to its fullest and maximize comfort for baby and you.



Enjoy!

Parts of the EuroTote

FRONT



Re-Installing the Carrying Board



"Foam"-side up,
strap-side down

- 1. Insert Board**
 Slide the carrying board in through the large horizontal slot and all the way until it stops.
 The foam side should face to the front of the bag and the side with straps attached should face towards the back of the bag.
- 2. Pull Straps through Holes**
 Reach inside the bag and insert the carrying straps through the four corresponding slots – two on each side of the bag. Make sure you insert them through the correct openings (not through the openings where the swaddle straps are attached).
- 3. Buckle**
 Re-buckle the carrying straps.

EuroTote Care Instructions

Lining: 100% cotton
 Shell & fill: 100% polyester

- Remove carrying board before washing (see instructions above).
- Machine wash cold separately, gentle cycle.
- Line dry.
- Do not bleach.
- Do not iron.
- Improper care will void any and all warranties.
- Carrying straps: hand wash/spot clean only.

The EuroTote as a Play Blanket

The EuroTote offers a clean and ready-to-go play blanket for hygienic play anywhere.




- 1. Unzip Top**
Unzip and take the top off.
- 2. Flatten Blanket and Hide Hood String**
Open hood so that the blanket is completely flat. Tuck hood string ends into the hood string pocket and close pocket with Velcro – out of reach from child.

DO NOT LEAVE CHILD UNATTENDED. DISCONTINUE USE AS PLAY BLANKET WHEN CHILD IS ABLE TO REACH HOOD STRING AND HIDDEN STRAPS.

Removing the Carrying Board


Before washing the EuroTote or when the child is too big for the Moses Carrier function, you should remove the carrying board:



Pull Carrying Board out


- 1. Tuck Carrying Straps into Holes**
Unbuckle the carrying straps and tuck them into the EuroTote through the four corresponding openings.
- 2. Pull Board out**
Open the bottom horizontal slot and pull the carrying board out. The carrying straps are attached to the board and will follow.
- 3. Store**
Store the carrying board until you need it again for using the EuroTote as a Moses Carrier, or reinstall after washing the EuroTote bag.

BACK




EuroTote as a Moses Carrier *with Warming Top*

When using the **warming top**, the side flaps and bottom flap should be folded **over** the child to provide maximum warmth.



1. Make a "Cocoon"

Place EuroTote on a flat surface. Tighten hood string to the shortest length with the string-clip and tie a knot to shorten and secure string. Tuck string into string pocket and close with Velcro.




2. Fold and Attach Foot Flap

Place child inside carrier with face up. Close zippers. Fold the foot flap over child at child's length. Attach the hook to the strap on the **front** of the carrier.

3. Close up Sides

Fold the side flaps **over** child. Buckle and securely tighten the swaddle straps over child.



4. Lift and Carry

Securely buckle and evenly adjust carrying straps before lifting. Close the straps together with strap clasp. Support carrier with your hands and arms when carrying.

**ALWAYS CARRY CHILD
HORIZONTALLY WITH FACE UP.**



Practical and Helpful Hints

- For maximum warmth, adjust the EuroTote to your child's length by attaching the bottom hook to the front *or* back of the bag.
- Also for maximum warmth; fold the side flaps over your child and attach the swaddle straps.
- Close up hood to protect against wind and cold.
- When not in use, fold hood over the back of the seat and tighten the hood strap to ensure the back stays up.
- Insert all straps into the corresponding pockets when not in use.
- Simplify getting ready by leaving the EuroTote in the stroller or car seat. As the top zips off, the EuroTote may also serve as a soft seat cover on warmer days.
- Two way zippers allow you to regulate your child's temperature by opening up or closing up as needed.
- Unbutton the front "storm flap" to block sun, or wind and rain.
- Zippers open on the bottom allowing growing feet (or dirty shoes) to stick out.



To-way zippers




Adjustable length

EuroTote as a Bunting/Stroller Bag

The EuroTote may be used as a bunting bag in strollers, car seats, bike trailers, ski sleds, etc. with both 3 and 5 point harnesses.

5-Point Harness



1. **Place EuroTote in Seat**
 - a. Place the EuroTote in the seat and open EuroTote to reach inside.
 - b. Pull stroller harness straps through the slot openings on the back of the EuroTote;
 - for 5-point harness use vertical slots.
 - for 3-point harness use vertical top slot.
 - c. Pull the bottom buckle through whichever of the two vertical slots located between your child's legs that is compatible to your child's size.


2. **Fasten Harness over Child**
Place child in seat and fasten safety harness over child.

Zip Up and Go

Ensure that all straps and buckles are stored away. Zip warming top to keep child warm.

Unzip or close the EuroTote to regulate your child's temperature as weather and temperature change.


3-Point Harness




EuroTote as a Moses Carrier *with Mesh Top*

When using the **mesh top** on warm days, the side flaps should be **rolled/folded in on each side of child**. The foot flaps should be folded down and attached **under** the EuroTote so that the mesh is the only fabric covering the baby, allowing for maximum airflow.

1. **Make a "Cocoon"**
Repeat step # 1 above (page 6).



2. **Fold and Attach Foot Flap**
Place child inside carrier with face up. Close zippers. Fold the foot flap under the carrier at child's length. Attach the hook to the strap on the **back** of the carrier.



3. **Close up Sides**
Roll or fold the side flaps on **each side** of child. Buckle and securely tighten the swaddle straps over child.


4. **Lift and Carry**
Repeat step # 4 above (page 6).

IMPORTANT!

The Moses Carrier is intended for children from 21" (53 cm) and 8 lb (3.5 kg) up to 25 lb (11 kg). Always carry child horizontally or with child's head slightly tipped upwards. Carry child over your shoulder by always supporting the carrier with your hands and arms. Lift carrier with bended knees.

Placing the EuroTote Moses Carrier with Child into a Car Seat

The EuroTote Moses Carrier (with carrying board inside) fits 5-point harnesses and may be used directly in most car seats as long as it does not interfere with the harness safety system.



Pull harness straps through slots



Fasten harness over child



Preparation

Lengthen the car seat harness straps.
Remove pillows and toys from car seat.

On the bottom of the carrier open the Velcro that blocks the slots. This will simplify getting the harness straps through the slots when you have placed the carrier and child in the seat.

1. Place into Car Seat

Place the carrier with child inside into the seat.

2. Pull Car Seat Harness Straps Through Back of EuroTote

Open the EuroTote as much as needed in order to reach inside.

Pull the car seat harness straps through the vertical slots on each side of child and over child's shoulders.

Pull the car seat crotch harness strap/buckle through whichever of the two slots between child's legs that is compatible to child's size.

3. Fasten Car Seat Harness over Child

Fasten and adjust harness over child as directed by car seat instructions.

Lifting the EuroTote Moses Carrier with Child out of a Car Seat

Reverse the motions described above by:

1. Unbuckle car seat harness straps. **Tuck** harness straps into the slots on each side of child and through the slot between child's legs.
2. Close up carrier (see page 4 for instructions).
3. Remove EuroTote Moses Carrier with child from car seat by lifting with one hand and supporting under the carrier with the other hand. Assist pulling the harness straps through the slots.
4. Reach under the EuroTote and close the Velcro over the slots on the bottom of the carrier.

EuroTote as Travel Bedding

The EuroTote offers familiarity and security when traveling and therefore makes it easier for your child to go to sleep. **Always lay your child on her back to sleep. Check child frequently for comfort and safety.**



Fold foot-flap to the back and attach hook

DISCONTINUE USE AS TRAVEL BEDDING IF CHILD IS ABLE TO REACH HOOD STRAPS OR SMALL PARTS

1. **IMPORTANT: Remove Carrying Board**
(See page 13 for instructions).
2. **Flatten Hood**
Open the hood string so that the back is completely flat. Tuck the hood string ends into the hood strap pocket and securely close pocket with Velcro – away from child's reach.
3. **Hide Straps and Buckles**
Safely insert the four swaddle straps into the EuroTote through the corresponding holes - away from child's reach. Make sure that no part of the strap sticks out.
4. **Adjust Length**
Adjust the EuroTote to child's length and attach the hook to the strap on **back** of the bag. Place child inside and sip up zippers.